

SERVICE BULLETIN SB00.01

Machines/Models: LX31/41/50 4WD **Serial Numbers:** 1000 to 3103

THIS BULLETIN IS **MANDATORY**.

THE PROCEDURE SPECIFIED IN THIS BULLETIN **MUST** BE PERFORMED IMMEDIATELY, FAILURE TO PERFORM THIS PROCEDURE COULD RESULT IN DEATH OR SERIOUS INJURY.

DATE: January 4, 2000

PURPOSE: To assure correct positioning of Axle Float Cylinder Fitting Adapters.

OPERATION REQUIRED: Determine position of Axle Float Cylinder Fitting Adapters and reposition if necessary.

REIMBURSEMENT: UpRight will reimburse the owner of record for 1/2 hour of labor at \$60.00 per hour and for travel (up to 100 miles) at \$0.50 per mile. Reimbursement will be made upon receipt by UpRight of your completed warranty claim form. Please reference SB00.01 on your warranty claim form.

PROCEDURE: Read all instructions thoroughly and refer to Figures 1 through 4 before starting.

1. Platform must be in stowed position and machine on firm level surface.
2. Remove cover on front of chassis exposing Axle Float Cylinder. See Figure 1.
3. Locate Tee Fitting Adapter and Elbow Fitting Adapter. See Figure 2.
4. Verify clearance between Jam Nut and Fitting Adapter is 3/32"(2.38mm) to 1/8"(3.17mm). See Figures 3 and 4.

NOTE: If clearance between Jam Nut and Fitting Adapter is within the range of 3/32"(2.38mm) to 1/8"(3.17mm), proceed to item #10. If clearance is not within that range, proceed to item #5.

5. Remove pilot hoses from Tee Fitting Adapter and Elbow Fitting Adapter. See Figures 3 and 4.
6. Loosen Jam Nuts on Fitting Adapters and turn Fitting Adapters until the clearance between Jam Nuts and Fitting Adapters is between 3/32"(2.38mm) to 1/8"(3.17mm). See Figures 3 and 4. **NOTE: Cylinder may have two Tee Fitting Adapters or one Tee and one Elbow Fitting Adapter.**
7. Tighten Jam Nuts on Fitting Adapters and torque to 10-12 in. lbs. (1.12-1.35 Nm).
NOTE: Verify clearance between Jam Nuts and Fitting Adapters remains at 3/32"(2.38mm) to 1/8"(3.17mm).
8. Reattach pilot hoses to Fitting Adapters and torque to 135-145 in. lbs. (15.25-16.38 Nm)
9. Perform Pre-Operation and Safety Inspection as instructed in the Operator Manual, to ensure proper operation of machine, and that fittings do not leak.
10. Elevate platform four feet, verify machine travels in creep speed. (20 ft. course in 38-45 seconds)

Continued on next page.

If you have any questions regarding this Service Bulletin, please contact the UpRight Product Support Department by telephone at (800) 926-5438 from within the USA or at (559) 891-5200 outside the USA or by FAX at (559) 891-8931.

SERVICE BULLETIN SB00.01

Machines/Models: LX31/41/50 4WD Serial Numbers: 1000 to 3103

11. Drive right front wheel onto a two inch block. **Front axle should not oscillate and should remain in a locked position.** Reverse wheel off of block, repeat procedure for left front wheel. **Front axle should not oscillate and should remain in a locked position.**
12. Reinstall cover on front of chassis.
13. If machine does not perform as described, place machine out of service and contact UpRight Product Support Department by telephone at (800) 926-5438 or (559) 891-5200.




Figure 1: Front of machine




Figure 2




Figure 3




Figure 4

If you have any questions regarding this Service Bulletin, please contact the UpRight Product Support Department by telephone at (800) 926-5438 from within the USA or at (559) 891-5200 outside the USA or by FAX at (559) 891-8931.