

Service Bulletin 05.04-1

AB62 Slave Cylinder

Machines affected : All AB62 models from serial number 1000 to Current

Issue Date : 14/04/05

Purpose To provide grease application point on slave cylinder head assembly.

Parts Affected Slave Cylinder Head Assembly

Parts Supplied	Cylinder Head	104258-005
	Circlip	011765-024
	Pivot Pin	104160-000
	Bushing	104375-000
	Grease Nipple	056819-000

Reimbursement Replacing these parts will take less than 30mins, *Ui* will reimburse for 30 (thirty) minutes labour at 66euro per hour.

(Please reference this Information Bulletin number SB05.04-1 on your warranty claim form)

Procedure Read these procedures carefully and understand them before beginning any operations. Refer to the diagrams and/or pictures

- 1. Safely support the cage assembly and booms.**
- 2. Remove the old circlip, pin and cylinder head (these are no longer required)**
- 3. Fit grease nipple to cylinder head.**
- 4. Screw the new cylinder head to slave cylinder, ensure that the pivot to pivot dimension of the cylinder meets 1143mm.**
- 5. Locate, lubricate and fit the new pivot pin.**
- 6. Secure the pivot pin with the supplied circlip.**
- 7. Pump grease into grease nipple until overflowing.**

Fully Assembled

