

Service Manual

ULII - 25/32/40

**Portable Personnel Lifts
European Model**

Serial Number 21525 - Current


P/N 068018-022

UpRight

ULII - 25/32/40

Portable Personnel Lifts

When contacting UpRight for service or parts information, be sure to include the MODEL and SERIAL NUMBERS from the equipment nameplate. Should the nameplate be missing, the SERIAL NUMBER is also stamped on the chassis tube on the right side of the mast.



UpRight Inc.	
1775 PARK ST. SELMA CALIFORNIA 93662 USA	
Model _____	Serial number: _____
Machine weight _____ lbs. _____ kg	Mfg. date: _____
Maximum allowable incline of machine when elevated: _____ deg.	
Occupants and equipment must not exceed the rated maximum load: _____ lbs. _____ kg	
Maximum platform occupants: _____	
Maximum allowable side force on platform: _____ lbs. _____ N	
Maximum platform height: _____ ft. _____ m	
Maximum platform reach: _____ ft. _____ m	
Maximum allowable wind speed: _____ mph _____ km/h	
Maximum hydraulic system pressure: _____ psi _____ bar	
Maximum system voltage: _____ vdc	
This machine is manufactured to comply with ANSI A92.5-1992.	
CAUTION: CONSULT OPERATOR'S MANUAL BEFORE USE.	
THIS PLATFORM IS NOT ELECTRICALLY INSULATED	
061205-002	

UpRight, Inc.

1775 Park Street
Selma, California 93662
TEL: 559/891-5200
FAX: 559/891-9012
PARTS: 1-888-UR-PARTS
PARTS FAX: 559/896-9244

UpRight

Call Toll Free in U.S.A.
1-800-926-LIFT

UpRight International Support Centre

Innsbruckweg 114
3047 AH Rotterdam
Netherlands
TEL: +31-10-238-0000
FAX: +31-10-238-0001
Parts Tel: +31-10-490-8090
Parts Fax: +31-10-490-8099

Table of Contents

Section Number	Page No.
1.0 Introduction	1-1
Purpose of Equipment	1-1
General Description	1-1
Platform	1-1
Mast	1-1
Chassis	1-1
Operator Controls	1-1
2.0 Introduction	4-1
Special Tools	4-1
2.1 Preventative Maintenance (Table 2-1)	4-1
Preventative Maintenance Table Key	4-2
Preventative Maintenance Report	4-2
2.2 Lubrication	4-3
Casters	4-3
Chains	4-3
Screw Jacks	4-3
Hydraulic Oil Reservoir (Figure 2-2)	4-3
2.3 Battery Maintenance	
(DC units only)	4-4
Battery Inspection and Cleaning	4-4
Battery Charging (Figure 2-3)	4-4
Battery Cell Equalization	4-5
2.5 Mast Assembly (Figure 2-6,2-7) Disassembly	4-6
Platform Assembly Removal	
(Figure 2-6)	4-6
#6 Mast	4-6
#5 Mast	4-6
#4 Mast	4-6
2.5 Mast Assembly (Cont.)	4-9
#3 Mast	4-9
#2 Mast	4-9
Assembly (Figure 2-7)	4-9
#2 Mast	4-9
#3 Mast	4-9
#4 Mast	4-9
#5 Mast	4-9
#6 Mast	4-9
2.5 Mast Assembly (Cont.)	4-10
Platform Support Assembly	4-10
Sequencing Strap Installation	4-10
2.6 Cylinder Assembly	4-10
Seal Replacement (Figure 2-8)	4-10
2.6 Cylinder Assembly (Cont.)	4-12
Orifice Valve Cleaning	4-12
Cylinder Removal (Figure 2-9)	4-13
Installation	4-13
2.6 Cylinder Assembly (Cont.)	4-14
Installation (Cont.)	4-14
Fasteners	4-14
2.7 Torque Specifications	4-14
Hydraulic Components	4-14
3.0 Introduction	5-1
General Procedure	5-1
4.0 Introduction	6-1
Index	6-1
4.1 Electrical Schematics	6-2
4.2 Hydraulic Schematic	6-4

List of Illustrations

Figure Number	Page No.
1-1 UL Portable Personnel Lifts	1-1
2-1 Lubrication	2-3
2-2 Hydraulic Power Unit	2-3
2-3 Battery Charger	2-5
2-4 System Relief Valve	2-5
2-5 Lifting / Lowering UL Lift	2-6
2-6 Mast Assembly, Strap and Chain Detail	2-7
2-7 Mast Assembly Bearing Detail	2-8
2-8 Lift Cylinder	2-11
2-9 Chain Tensioning, Cylinder Installation	2-13
3-1 Circuit Board	3-5
3-1 Electrical Schematic, AC Models	3-3
3-2 Electrical Schematic, DC Models	3-3
3-3 Hydraulic Schematic	3-4

List of Tables

Table Number	Page No.
1-1 Specifications	1-2
2-1 Preventative Maintenance	2-2
2-2 Hydraulic Component Torque	2-14
2-2 Bolt Torque	2-14
3-1 Troubleshooting	3-2
4-1 Electrical Schematic Legend, AC	4-2
4-2 Electrical Schematic Legend, DC	4-2
4-3 Hydraulic Schematic Legend	4-4

Foreword

Introduction

HOW TO USE THIS MANUAL

This manual is divided into 4 sections plus a copy of the *Operator Manual*. The section number is printed at the top corner of each page.

SPECIAL INFORMATION

⚠ DANGER ⚠
Indicates the hazard or unsafe practice <i>will</i> result in severe injury or death.

⚠ WARNING ⚠
Indicates the hazard or unsafe practice <i>could</i> result in severe injury or death.

⚠ CAUTION ⚠
Indicates the hazard or unsafe practice could result in <i>minor</i> injury or property damage.

NOTES: Give helpful information.

WORKSHOP PROCEDURES

CAUTION: Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. Please note that this manual does contain warnings and cautions against some specific service methods which could cause personal injury, or could damage a machine or make it unsafe. Please understand that these warnings cannot cover all conceivable ways in which service, whether or not recommended by UpRight, Inc., might be done, or of the possible hazardous consequences of each conceivable way, nor could UpRight Inc. investigate all such ways. Anyone using service procedures or tools, whether or not recommended by UpRight Inc., must satisfy themselves thoroughly that neither personal safety nor machine safety will be jeopardized.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at any time without notice. No part of this publication may be reproduced, stored in retrieval system, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

Introduction & Specifications

General description and machine specifications.

1.0

Operator Manual

Operating instructions and safety rules.

Maintenance

Preventative maintenance and service information.

2.0

Troubleshooting

Causes and solutions to typical problems.

3.0

Schematics

Schematics and valve block diagram with description and location of components.

4.0

Foreword

NOTES

1.0 Introduction

PURPOSE OF EQUIPMENT

The UpRight Personnel Lift is a portable lift designed to elevate personnel and light equipment to work above the ground.

GENERAL DESCRIPTION

There are three basic UpRight Personnel Lift models: the UL-25, UL-32 and the UL-40.

All models consist of a Platform, Mast and Chassis.

The UL-32 and UL-40 are equipped with a tilt back mechanism to facilitate passage through a standard 2 m (80 in.) doorway. This tilt back mechanism is optionally available in a configuration adapted to fit the UL-25.

Platform

The platform is an aluminum structure supported by a steel cage support attached to the mast. It has 110,5 cm (43.5 in.) high "clamshell" upper and lower guardrail assembly with gas spring assist for opening and closing, six (6) inch toeboards and integrated midrail.

Mast

The platform is raised and lowered by a seven stage mast assembly that is driven by a single stage hydraulic lift cylinder and a series of leaf chains. An AC or DC electric motor powers a hydraulic pump which in turn energizes the cylinder. Solenoid operated valves control the raising and lowering of the Platform.

Chassis

The Chassis is a steel structure that consists of the first stage of the Mast Assembly, control box, battery charger (for DC Models), and AC or DC Motor, hydraulic pump and reservoir, 12v battery (for DC Models), a tilt back assembly (standard on UL-32, and UL-40 machines, optional on UL-25 machines), and four Outriggers. The chassis is equipped with outrigger status lights which indicate that outrigger interlock switches are closed

Operator Controls

Controls consist of a Lower Emergency Stop Switch, Upper Emergency Stop Switch, Key Switch and three (3) push button controls: Power On, Up, Down. The Power On button must be pushed along with the Up or Down button to operate the machine. An Emergency Lowering Valve is located on the power unit at the base of the machine.




Figure 1-1: UL Portable Personnel Lift

Table 1-1: Specifications

ITEM	UL25	UL32	UL40
Platform Height			
Maximum	7,62 m (25 ft.)	9,75 m (32 ft.)	12,19 m (40 ft.)
Minimum	38 cm (15 in.)	38 cm (15 in.)	38 cm (15 in.)
Platform Capacity	159 kg (350 lbs.)	136 kg (300 lbs.)	136 kg (300 lbs.)
Stored Dimensions			
Vertical Height	1,98 m (78 in.)	2,53 m (99.5 in.)	114 in. (2,90 m)
Width	0,74 m (29 in.)	0,74 m (29 in.)	0,74 m (29 in.)
Depth	1,26 m (49.5 in.)	1,32 m (52.5 in.)	1,32 m (52.5 in.)
Diagonal Storage Height	-	1,98 m (78 in.)	1,98 m (78 in.)
Diagonal Storage Length	-	2,53 m (99.5 in.)	2,9 m (114 in.)
Footprint (outriggers extended)			
Width	1,5 m (59 in.)	2,06 m (81 in.)	2,34 m (92 in.)
Length	1,42 m (56 in.)	1,98 m (78 in.)	2,26 m (89 in.)
Weight-overall AC:	349 kg (770 lbs.)	417 kg (920 lbs.)	449 kg (990 lbs.)
Weight-overall DC:	367 kg (810 lbs.)	435 kg (960 lbs.)	467 kg (1,030 lbs.)
Set of Outriggers & Screwjacks	21 kg (46 lbs.)	25 kg (54 lbs.)	30 kg (66 lbs.)
Guardrail Height	1,11m (43.5 in.)	1,11m (43.5 in.)	1,11m (43.5 in.)
Toe Board Height	152 mm (6 in.)	152 mm (6 in.)	152 mm (6 in.)
Max. System Voltage	120 VAC 60 Hz or 220 VAC 50/60 Hz		
AC Electric Motor	1-12 Volt Battery, Grp. 27		
DC Electric Power Source	105 Amp/Hrs., Min. Wt. 23,6 kg (52 lbs.)		
Battery Charger	Automatic, 120 VAC 60 Hz or 220 VAC 50 Hz		
	Output: 10 Amps, 12 Volts D.C.		
Maximum Hydraulic System Pressure	165 bar (2400 PSI)		

***Specifications subject to change without notice.**

OPERATION MANUAL

WARNING

All personnel shall carefully read, understand and follow all safety rules and operating instructions before operating or performing maintenance on any UpRight aerial work platform.

Safety Rules

Electrocution Hazard



THIS MACHINE IS NOT INSULATED!

Tip Over Hazard



NEVER elevate the platform unless all four (4) outriggers have been properly installed.



NEVER elevate the platform without first leveling the base.



NEVER attempt to push the UpRight Lift with people or materials on the platform or with the platform elevated.

Collision Hazard



NEVER position the platform without first checking for overhead obstructions or other hazards.

Fall Hazard



NEVER climb, stand, or sit on platform guardrails or midrail.

THIS MACHINE IS FOR INDOOR USE ONLY! Do not use out of doors.

USE OF THE AERIAL WORK PLATFORM: This aerial work platform is intended to lift persons and his tools as well as the material used for the job. It is designed for repair and assembly jobs and assignments at overhead workplaces (ceilings, cranes, roof structures, buildings etc.). All other uses of the aerial work platform are prohibited!

THIS AERIAL WORK PLATFORM IS NOT INSULATED! For this reason it is imperative to keep a safe distance from live parts of electrical equipment!

Exceeding the specified permissible maximum load **is prohibited!** See "Special Limitations" on page 4 for details.

The use and operation of the aerial work platform as a lifting tool or a crane (lifting of loads from below upwards or from up high on down) **is prohibited!**

NEVER exceed the manual force allowed for this machine. See "Special Limitations" on page 4 for details.

DISTRIBUTE all platform loads evenly on the platform.

NEVER operate the machine without first surveying the work area for surface hazards such as holes, drop-offs, bumps, curbs, or debris; and avoiding them.

OPERATE machine only on surfaces capable of supporting wheel loads.

IN CASE OF EMERGENCY push EMERGENCY STOP switch to deactivate all powered functions.

Climbing up the railing of the platform, standing on or stepping from the platform onto buildings, steel or prefab concrete structures, etc., **is prohibited!**

Dismantling the entry gate or other railing components **is prohibited!** Always make certain that the entry gate is closed and securely locked!

It is prohibited to keep the entry gate in an open position (held open with tie-straps) when the platform is raised!

To extend the height or the range by placing of ladders, scaffolds or similar devices on the platform **is prohibited!**

NEVER perform service on machine while platform is elevated without blocking elevating assembly.

INSPECT the machine thoroughly for cracked welds, loose or missing hardware, hydraulic leaks, loose wire connections, and damaged cables or hoses before using.

VERIFY that all labels are in place and legible before using.

NEVER use a machine that is damaged, not functioning properly, or has damaged or missing labels.

To bypass any safety equipment **is prohibited** and presents a danger for the persons on the aerial work platform and in its working range.

NEVER charge batteries near sparks or open flame. Charging batteries emit explosive hydrogen gas.

Modifications to the aerial work platform **are prohibited** or permissible only at the approval by UpRight.

AFTER USE, secure the work platform from unauthorized use by turning keyswitches off and removing key.

CONTENTS

Introduction	3
General Description	3
Special Limitations	4
Platform Capacity	4
Manual Force	4
Controls and Indicators	5
Outrigger Installation	6
Safety Interlock Test	6
Pre-Operation Safety Inspection	7
System Function Inspection	7
Perform all tests from the ground	7
Operation	8
Elevating the Platform	8
Lowering the Platform	8
Emergency Lowering	8
Transporting the Work Platform	9
DC Models	9
Loading	9
Unloading	10
DC Models	10
Passage Through a Doorway	11
Lowering	11
Raising	11
Maintenance	13
Battery Maintenance	13
Battery Charging	13
Inspection and Maintenance Schedule	14
Daily Preventative Maintenance Checklist	14
Labels	16
Specifications	18

INTRODUCTION

This manual covers operation of the UL25, UL32, and UL40 Work Platforms. **This manual must be stored on the machine at all times.**


GENERAL DESCRIPTION

! WARNING !

DO NOT use the maintenance platform without guardrails properly assembled and in place

Figure 1: Work Platform

1. Platform
2. Mast
3. Chassis
4. Outriggers
5. Upper Guardrail (Gate)
6. Lower Guardrail
7. Chassis Controls
8. Power Unit
 - Motor
 - Hydraulic Reservoir
9. Battery Box (DC Units)
 - Battery
 - Battery Charger
10. Casters
11. Rear Wheels
12. Screw Jacks
13. Loader Assembly
14. Gate Latch Pin



SPECIAL LIMITATIONS

Elevating the Work Platform is limited to firm, level surfaces only.

All four (4) outriggers must be properly installed before operating the machine.

This machine is rated for indoor use only.



The elevating function shall ONLY be used when the work platform is level and on a firm surface.

PLATFORM CAPACITY

The maximum platform capacity for the MACHINE is:

- UL 25 - 159 kg (350 lbs).
- UL 32 and UL 40 - 136 kg (300 lbs).

One person may occupy the platform .



DO NOT exceed the maximum platform capacity or the platform occupancy limits for this machine.

MANUAL FORCE

Manual force is the force applied by the occupants to objects such as walls or other structures outside the work platform.

The maximum allowable manual force is limited to 200 N (45 lbs.) of force.




DO NOT exceed the maximum amount of manual force for this machine.

CONTROLS AND INDICATORS



Figure 2: Controls and Indicators

Platform Controls




- 1 Emergency Stop Switch
- 2 Power On Button
- 3 Up Button
- 4 Down Button
- 5. Battery Charger

Chassis Controls




- 1 LED (Indicates that optional Emergency Down from the platform battery needs replacing).
- 2. Emergency Stop Switch
- 3. Key Switch
- 4. Emergency Lowering Valve
- 5. Orbit Level
- 6. Outrigger Indicator Lights



OUTRIGGER INSTALLATION

1. Remove the outriggers from storage locations on the sides of the mast.
2. Insert into the outrigger socket in the base (Figure 1).
3. Push in until the locking pin engages the hole in the end of the outrigger. Pull outward on the outrigger to ensure engagement.
4. Repeat the above steps for all other outriggers. Make sure all four (4) locking pins are engaged.
5. Level the base, centering the bubble in the orbit level on the base by adjusting the screwjacks (turn clockwise) at the end of each outrigger. DO NOT release the tension (turn counterclockwise) on an outrigger to level the base.
6. All four (4) screwjack pads must be in solid contact with a firm surface and each outrigger indicator light must be lit before the platform is elevated.

Figure 3: Installing Outriggers



SAFETY INTERLOCK TEST

⚠ DANGER ⚠

NEVER perform this test from the platform.

1. Properly install all four (4) outriggers and level the base.
2. Release the tension on one (1) outrigger by turning the screwjack counter clockwise until the indicator light is no longer lit.
3. While standing on the ground, activate the control panel to elevate the platform. **The platform should not elevate.**
4. Re-level the base.
5. Repeat steps 2, 3 and 4 until all four (4) outriggers have been tested.

⚠ DANGER ⚠


DO NOT use a machine that elevates when the tension has been released on an outrigger. The machine must be repaired before using.

PRE-OPERATION SAFETY INSPECTION

NOTE: Carefully read, understand and follow all safety rules, operating instructions, labels and National Safety Instructions/Requirements. Perform the following steps each day before use.

1. Check that all four (4) outriggers are properly installed.
2. Check that the base is level.
3. **AC Units:** connect the power unit plug to an approved extension cord.
4. **DC Units:** Verify that batteries are charged.
5. Perform the Safety Interlock test.
6. Check for external damage to the mast.
7. Check the level of the hydraulic fluid with the platform fully lowered:
 - Remove the reservoir cap and check the fluid level on the dipstick.
 - Add hydraulic fluid if necessary.
8. Check that fluid level in the batteries is correct. See “Battery Maintenance” on page 13.
9. Check that all guardrails are in place and all fasteners are properly tightened.
10. Inspect the machine thoroughly for cracked welds and structural damage, loose or missing hardware, hydraulic leaks, damaged control cable, and loose wire connections.

Figure 4: Hydraulic Reservoir



SYSTEM FUNCTION INSPECTION

Refer to Figure 2: “Controls and Indicators,” on page 5 for the locations of various controls and indicators.

⚠ WARNING ⚠

STAND CLEAR of the work platform while performing the following checks.

Check above the work platform for obstructions and electrical conductors.

NOTE: The platform will not elevate unless all four outriggers are properly installed with screwjack pads firmly in contact with floor and each outrigger indicator lamp lit.

PERFORM ALL TESTS FROM THE GROUND

1. Pull the Chassis Emergency Stop Switch to the ON position.
2. Turn the Key to ON.
3. Pull the Platform Emergency Stop Switch to the ON position.
4. Push both the middle and top buttons (POWER and UP) on the Control Box at the same time to elevate the platform. Release the buttons to stop.
5. Push both the middle and bottom buttons (POWER and DOWN) at the same time to lower the platform. Release the buttons to stop.
6. Open the Emergency Lowering Valve to verify proper operation.
7. Push the Chassis Emergency Stop Switch to verify proper operation. All machine functions should be disabled. Pull out the Chassis Emergency Stop Switch to resume.
8. Push the Platform Emergency Stop Switch to verify proper operation. All machine functions should be disabled. Pull out the Platform Emergency Stop Switch to resume.

OPERATION

Before operating the machine, ensure that the Pre-Operation Safety Inspection has been completed and that any deficiencies have been corrected. **Never operate a damaged or malfunctioning machine.** The operator must be thoroughly trained on this machine.

NOTE: The platform will not elevate unless all four outriggers are properly installed with screwjack pads firmly in contact with floor and each outrigger indicator lamp lit.

1. **AC Units:** connect the power unit plug to an approved extension cord.
2. **DC Units:** verify that the battery charger is turned OFF and that the extension cord is removed.
3. Pull the Chassis Emergency Stop Switch to the ON position.
4. Turn the Key to ON.
5. Enter the platform by pulling out on the locking pin and lifting up on the upper half of the cage.
6. Lower upper half of the cage after entering platform making sure locking pin is engaged.

ELEVATING THE PLATFORM

7. Check that the area above the platform is clear before elevating the platform.
8. Pull the Platform Emergency Stop Switch to the ON position.
9. Push both the middle and top buttons (POWER and UP) on the Control Box at the same time to elevate the platform. Release the buttons to stop.
 - In the event of an emergency, push the Emergency Stop Button.
10. Visually inspect the mast assembly for cracked welds and structural damage, loose hardware, hydraulic leaks, loose wire connections, and erratic operation. Check for missing or loose parts.

LOWERING THE PLATFORM

11. Check that the area below the platform is clear before lowering the platform.
12. Push both the middle and bottom buttons (POWER and DOWN) at the same time to lower the platform. Release the buttons to stop.

EMERGENCY LOWERING

Refer to Figure 2: "Controls and Indicators," on page 5 for the location of the Emergency Lowering Valve.

! WARNING !

If the platform should fail to lower, NEVER climb down the elevating assembly.

Stand clear of the elevating assembly while operating the Emergency Lowering Valve Knob.

Ask a person on the ground to open the Emergency Lowering Valve to lower the platform. This valve is located at the rear of the machine.

1. Pull the knob to open the valve.
2. To close the valve, release the knob.

NOTE: The platform will not elevate if the Emergency Lowering Valve is open.

TRANSPORTING THE WORK PLATFORM

DC MODELS

Disconnect the plug from the battery box and remove the battery box from the rear of the machine.

Figure 5: Battery Box (DC Models Only)

CAUTION

The battery box is heavy, 23,6 kg (52 lbs.). Lift properly to prevent back injury.


LOADING

Refer to Figure 6: "Loading the UL for Transportation," on page 10.

WARNING

Make sure the loader fully engages the tailgate or vehicle bed.

1. Raise the loader support brackets and engage the retaining pin in the top hole of the loader channel.
2. Secure the loader to the loader support bracket with the gravity hook.
3. Position the unit so the back of the machine comes into contact with the tailgate or vehicle bed.
4. Release the gravity hook and slide the loader down until it comes into contact with the tailgate or vehicle bed. Then reposition the loader support bracket so that the retaining pin is in the **first** available hole above the loader.
5. Release the locking pin and pull the T-handle out until the locking pin engages the hole in the end of the T-handle.
6. Lift up on the T-handle, using the loader as a pivot, until the unit rotates to a horizontal position in the vehicle bed.
7. Push the base of the unit towards the front of the vehicle bed. The machine will slide on the loader until the rear wheels are on the bed. The unit may then be rolled on the rear wheels and upper casters.
8. Return the T-handle to the stored position, making sure that the locking pin engages the T-handle.
9. Secure the unit with suitable tie straps using the forklift pockets located under the base of the unit, and either the upper caster axle on the UL25 models or the tilt back frame on the UL32 and UL40 models.



CAUTION

To prevent damage to the mast assembly, do not place rope or tie straps across the mast assembly when securing the unit for transportation.

DO NOT overtighten the rope or tie straps or damage to the machine will result.


UNLOADING

1. Unsecure the unit.
2. Release the locking pin and pull the T-handle out until the locking pin engages the hole in the end of the T-handle.
3. Roll the unit back until the rear wheels are off the edge of the tailgate or vehicle bed.
4. Pull downward on the T-handle, allowing the unit to slide on the loader.
 - As the unit stops sliding on the loader, it will pivot on the loader to an upright position.
 - Gradually counterbalance the unit's weight by applying an upward force on the T-handle. This allows the unit to settle gently on the wheels, avoiding undue impact on the unit.
5. Return the T-handle to the stored position, making sure that the locking pin engages the T-handle.

DC MODELS

Replace the battery and reconnect the battery box plug, making certain it is fully engaged.

Figure 6: Loading the UL for Transportation



PASSAGE THROUGH A DOORWAY

The UL32 and UL40 are equipped with a castered rear Tilt Back assembly. When the unit is tilted back onto this support frame, the overall height is reduced to allow the unit to pass through a standard doorway.

Refer to Figure 7: "Passing Through Doorways," on page 12.

LOWERING

CAUTION

Before tilting the machine onto the rear Tilt Back assembly, be sure that the retaining pin is fully inserted with the hair pin retainer installed and the cylinder assembly is fully extended.

DO NOT drop the Tilt Back frame.


Keep out from under the Tilt Back frame and machine when tilting.

1. Be sure that the area is clear of personnel and obstructions.
2. While holding the Tilt Back frame, remove the hair pin retainer and the retaining pin.
3. Lower the Tilt Back frame until the hole in the cylinder assembly align with the upper mounting bracket pin hole. Secure the cylinder assembly to the upper mounting bracket using the retaining pin and hair pin retainer.
4. Extend the Tilt Back Handle to the tilt/lift position by releasing the locking pin and pulling the handle out of the Tilt Back assembly until the locking pin engages.
5. Push down on the Tilt Back Handle until the unit comes to rest on the Tilt Back frame.
 - As the mast tilts back, counterbalance the machine's weight by increasing upward force on the end of the Tilt Back Handle. This allows the machine to gently come to rest on the Tilt Back casters.
6. Pull down on the handle on the back of the mast to compress the cylinder assembly.
7. Return the Tilt Back Handle to the storage position, making sure that the locking pin engages the handle.


RAISING

1. Lift up on the mast handle to extend the cylinder assembly.
2. Fully engage the Tilt Back Handle until the locking pin engages.
3. Lift up on the Tilt Back Handle.
 - As the mast approaches vertical, counterbalance the machine's weight by increasing downward force on the end of the tilt Back Handle. This allows the machine to settle gently on the front casters.
4. Return the Tilt Back handle to the storage position, making sure that the locking pin engages the handle.
5. While holding the Tilt Back frame, remove the retaining pin and raise the Tilt Back assembly to the stowed position.
6. Secure with the retaining pin, making sure that the retaining pin is fully inserted, and that the hair pin retainer is installed.

Figure 7: Passing Through Doorways



Cylinder Secured with Retaining Pin



Lowering and Raising with the Tilt Back Handle



Compressing the Cylinder Assembly

MAINTENANCE

BATTERY MAINTENANCE

⚠ WARNING ⚠

Hazard of explosive gas mixture. Keep sparks, flame, and smoking material away from batteries.

Always wear safety glasses when working near batteries.

Battery fluid is highly corrosive. Thoroughly rinse away any spilled fluid with clean water.

Always replace batteries with UpRight batteries or manufacturer approved replacements weighing 22 kg (48 lbs.) each.

- Check the battery fluid level daily, especially if the work platform is being used in a warm, dry climate.
- If electrolyte level is lower than 10 mm ($\frac{3}{8}$ in.) above the plates add distilled water only. DO NOT use tap water with high mineral content, as it will shorten battery life.
- Keep the terminals and tops of the batteries clean.
- Refer to the Service Manual to extend battery life and for complete service instructions.

BATTERY CHARGING

Charge the batteries at the end of each work shift or sooner if the batteries have been discharged.

⚠ WARNING ⚠

Charge the batteries in a well ventilated area.

Do not charge the batteries when the work platform is near a source of sparks or flames.

Permanent damage to the batteries will result if the batteries are not immediately recharged after discharging.

Never disconnect the cables from the batteries when the charger is operating.


Keep the charger dry.

1. Check the battery fluid level. If the battery fluid level is lower than 10 mm ($\frac{3}{8}$ in.) above the plates add distilled water only.
2. Verify the charger voltage switch is set to 12 volts.
3. Connect an appropriate extension cord to the charger plug. Plug the extension cord into a properly grounded outlet of proper voltage and frequency.
4. Turn the charger timer knob to 12. The charger ammeter should indicate the charge rate.
5. When the battery is fully charged, turn the knob to OFF, do not turn the knob to HOLD. Disconnect the extension cord.

NOTE: The battery charger circuit must be used with a GFI (Ground Fault Interrupt) outlet.

NOTE: DO NOT operate the machine while the charger is plugged in.

Figure 8: Battery Charger



INSPECTION AND MAINTENANCE SCHEDULE

The Complete Inspection consists of periodic visual and operational checks, along with periodic minor adjustments that assure proper performance. Daily inspection will prevent abnormal wear and prolong the life of all systems. The inspection and maintenance schedule should be performed at the specified intervals. Inspection and maintenance shall be performed by personnel who are trained and familiar with mechanical and electrical procedures.



Before performing preventative maintenance, familiarize yourself with the operation of the machine. Always block the elevating assembly whenever it is necessary to perform maintenance while the platform is elevated.

The daily preventative maintenance checklist has been designed for machine service and maintenance. Please photocopy the Daily Preventative Maintenance Checklist and use the checklist when inspecting the machine.

DAILY PREVENTATIVE MAINTENANCE CHECKLIST

MAINTENANCE TABLE KEY

- Y = Yes/Acceptable
- N = No/Not Acceptable
- R = Repaired/Acceptable

PREVENTATIVE MAINTENANCE REPORT

Date: _____

Owner: _____

Model No: _____

Serial No: _____

Serviced By: _____


COMPONENT	INSPECTION OR SERVICES	Y	N	R
Battery	Check electrolyte level.			
	Check battery cable condition.			
Chassis	Check bubble level accuracy			
	Check operation of outrigger interlocks			
	Check casters for damage			
	Check hoses for pinch or rubbing points.			
	Check welds for cracks.			
Control Cable	Check the exterior of the cable for pinching, binding or wear.			
Controller	Check switch operation.			
Mast Assembly	Inspect for bends, cracks or loose rivets.			

COMPONENT	INSPECTION OR SERVICES	Y	N	R
Emergency Lowering System	Operate the emergency lowering valve and check for serviceability.			
Hydraulic Fluid	Check fluid level.			
Hydraulic Pump	Check for hose fitting leaks.			
Hydraulic System	Check for leaks.			
Labels	Check for peeling, missing, or unreadable labels & replace.			
Cage and Deck	Check welds for cracks.			
	Check condition of deck.			

NOTES:

LABELS

These labels shall be present and in good condition before operating the work platform. Be sure to read, understand and follow these labels when operating the work platform.



1 010076-901

THIS MACHINE IS FOR INDOOR USE ONLY! Do not use out of doors.

USE OF THE AERIAL WORK PLATFORM: This aerial work platform is intended to lift persons and its tools as well as the material used for the job. It is designed for repair and assembly jobs and is not intended for overhead workplaces (ceilings, cranes, roof structures, buildings etc.). All other uses of the aerial work platform are prohibited!

THIS AERIAL WORK PLATFORM IS NOT INSULATED! For this reason it is imperative to keep a safe distance from live parts of electrical equipment! Exceeding the specified permissible maximum load is PROHIBITED!

Read operator's manual for more details.

The use and operation of the aerial work platform as a lifting tool or a crane IS PROHIBITED.

NEVER exceed the manual force allowed for this machine.

Read operator's manual for more details.

DISTRIBUTE all platform loads evenly on the platform.

NEVER operate the machine without first surveying the work area for surface hazards such as holes, drop-offs, bumps, curbs, or debris, and avoiding them.

OPERATE machine only on surfaces capable of supporting wheel/outrigger loads.

IN CASE OF EMERGENCY push emergency stop switch to deactivate all powered functions.

Climbing up the railing of the platform, standing on or stepping from the platform onto buildings or other structures, IS PROHIBITED.

Dismantling the swing gate or other railing components IS PROHIBITED!

Always make certain that the swing gate is closed and securely locked!

IT IS PROHIBITED to keep the swing gate or other bar in an open position when the platform is raised!

To extend the height or range by placing of ladders, scaffolds or similar devices on the platform IS PROHIBITED.

NEVER perform service on machine while platform is elevated without blocking lowering assembly.

INSPECT the machine thoroughly for cracked welds, loose or missing hardware, hydraulic leaks, loose connections, and damaged cables or hoses before using.

VERIFY that all labels are in place and legible before using.

NEVER use a machine that is damaged, not functioning properly, or has damaged or missing labels.

To bypass any safety equipment IS PROHIBITED and presents a danger for the persons on the aerial work platform and in its working range.

NEVER charge batteries near sparks or open flame. Charging batteries emit explosive hydrogen gas.

Modifications to the aerial work platform are prohibited or permissible only at the approval by UpRight.

AFTER USE, secure the work platform from unauthorized use by turning the keyswitch off and removing key.

2 067195-003
English

DIESE MASCHINE NUR IN INNENRÄUMEN BENUTZEN! Diese Maschine nicht im Freigebiet einsetzen.

VERWENDUNG DER HOCHARBEITSBÜHNE: Diese Hocharbeitsbühne dient zum Heben von Personen und deren Werkzeugen sowie des für die Arbeit benötigten Materials. Sie ist für die Ausführung von Reparatur- und Montagearbeiten an hochgelegenen Arbeitsplätzen (Decken, Köpfe, Dachkonstruktionen, Gebäuden usw.) vorgesehen. Sämtliche anderen Einsatzbereiche der Hocharbeitsbühne sind verboten!

DIESE HOCHARBEITSBÜHNE IST NICHT ISOLIERTE! Aus diesem Grund ist es dringend erforderlich, einen ausreichenden Abstand zwischen der Hocharbeitsbühne und elektrischen Teilen zu gewährleisten!

Es ist verboten, die zulässige Hochhubbelastung zu überschreiten! Lesen Sie das Handbuch des Bedieners für mehr Einzelheiten.

Das Verwenden bzw. der Betrieb der Hocharbeitsbühne als Hebevorrichtung oder Kran ist verboten!

Den vorgeschriebenen manuellen Kraftaufwand NIE überschreiten. Lesen Sie das Handbuch des Bedieners für mehr Einzelheiten.

Alle Lasten stets gleichmäßig auf der Arbeitsbühne verteilen!

Machine NEMALS in Betrieb nehmen, ohne zuvor das Arbeitsgebiet auf Bodenrinnen, Löcher, Kanten, Dachkonstruktionen, Gebäuden usw. untersucht, Penetration oder Schutz zu untersuchen und diese zu umgehen.

Maschine nur auf standfesten BETREIBEN, deren Tragfähigkeit für die Lasten ausreicht.

BEI NOTFÄLLEN den Notauslöser drücken, um alle Antriebsfunktionen zu deaktivieren.

Es ist verboten, das Getriebe der Arbeitsbühne zu betätigen, auf diesem zu stehen oder von der Arbeitsbühne her Gebäude, Stahl- oder vorgefertigte Bauteile zu betätigen.

Der Abbau der Tür oder anderer Teile des Getriebes ist verboten! Es ist immer zu kontrollieren, ob die Tür geschlossen und sicher verriegelt ist!

Es ist verboten, die Tür offen zu lassen, wenn die Arbeitsbühne angehoben wird!

Es ist verboten, die Höhe bzw. Reichweite der Arbeitsbühne durch Ausfahren von Leitern, Gerüsten oder ähnlichen Gegenständen zu vergrößern!

An der Maschine NEMALS Wartungsarbeiten durchführen, wenn die Arbeitsbühne hochgefahren ist, ohne das Hubgestütz zu blockieren!

Maschine vor Benutzung gründlich auf gereinigte Schweißnähte, lose oder fehlende Metallteile, Hydrauliklecks, lose Kabelanschlüsse und beschädigte Kabel oder Schläuche ÜBERPRÜFEN!

Vor Benutzung SICHERSTELLEN, dass alle Schalter angebracht und gut lesbar sind.

Machine NEMALS in Betrieb nehmen, wenn diese beschädigt ist, nicht einwandfrei funktioniert oder deren Schilder beschädigt sind oder fehlen.

Die Außenabwärtzung von Sicherheitsvorrichtungen ist verboten und stellt für die auf der Hocharbeitsbühne und in ihrer Reichweite befindlichen Personen eine Gefahr dar.

Batterien NEMALS in der Nähe von Funken oder bei offener Flamme aufladen.

Beim Laden von Batterien wird explosive Wasserstoffgas freigesetzt.

Modifikationen der Hocharbeitsbühne sind verboten bzw. nur mit Genehmigung von UpRight zulässig.

Arbeitsbühne NACH GEBRAUCH vor unzulässiger Benutzung sichern, indem alle Schlüsselstecker ausgeschaltet werden und der Schlüssel abgezogen wird.

3 067195-203
Deutsch

CETTE MACHINE EST CONÇUE POUR N'ÊTRE UTILISÉE QU'À L'INTÉRIEUR! Ne pas utiliser à l'extérieur.

USAGE DE LA PLATE-FORME ÉLEVATRICE: Cette plate-forme élévatrice est destinée au levage de toute personne, de son outillage et des matériaux utilisés sur le chantier. Elle est conçue pour les travaux de réparations et d'assemblage sur les points élevés (plafonds, grues, charpentes de toit, immeubles, etc.). Tout autre usage de la plate-forme élévatrice est interdit!

CETTE PLATE-FORME ÉLEVATRICE N'EST PAS ISOLÉE! Il est impératif d'être à distance sûre des lignes et équipements électriques sous tension.

Il est interdit de dépasser la charge maximum admissible. Lisez le manuel de l'opérateur pour plus de détails.

Il est interdit d'utiliser la plate-forme comme appareil de levage ou grue.

NE JAMAIS dépasser la force manuelle autorisée pour cette machine.

Lisez le manuel de l'opérateur pour plus de détails.

REPARER uniformément toutes les charges placées sur la plate-forme.

NE JAMAIS utiliser la machine sans avoir d'abord vérifié si la zone de travail est exempte de dangers tels que des trous, dénivellements, bosses, trottoirs ou débris, et les éviter.

N'UTILISER la machine que sur des surfaces pouvant supporter la charge des roues.

EN CAS D'URGENCE, appuyer sur le bouton d'ARRÊT D'URGENCE pour désactiver toutes les fonctions.

Il est interdit de monter ou de se tenir sur les garde-corps de la plate-forme ou de passer de la plate-forme à une immeuble, une structure préfabriquée etc.

Il est interdit de retirer le portillon, ou toute autre pièce de garde-corps!

Toujours vérifier que le portillon est fermé et verrouillé.

Il est interdit de maintenir le portillon en position ouverte lorsque la plate-forme est élevée.

Il est interdit d'accrocher la hauteur ou la portée de la plate-forme au moyen d'échelles, échafaudages ou autres dispositifs similaires.

NE JAMAIS effectuer de travaux d'entretien sur la machine, si la plate-forme est en position élevée, sans tout d'abord bloquer le dispositif d'élevation.

INSPECTER minutieusement la machine en vue de soudures fissurées, de pièces de boulonnerie manquantes ou desserrées, de fuites hydrauliques, de branchements électriques desserrés ou de câbles et flexibles endommagés avant d'utiliser la machine.

VÉRIFIER que tous les interrupteurs sont en place et lisibles avant d'utiliser la machine.

NE JAMAIS utiliser une machine qui est endommagée, qui ne fonctionne pas correctement ou dont les autocollants sont manquants ou endommagés.

Il est interdit de mettre tout dispositif de sécurité hors service, ce qui mettrait en danger les personnes à bord de la plate-forme et celles se trouvant dans la zone de travail.

NE JAMAIS charger les batteries à proximité d'étincelles ou d'une flamme vive.

Lors de la charge, les batteries dégagent de l'hydrogène, un gaz explosif.


Sauv autorisation de la part d'UpRight, toute modification de la plate-forme est interdite.

APRES AVOIR UTILISÉ la plate-forme élévatrice, mettre les contacteurs à clé en position d'arrêt, puis retirer la clé afin d'empêcher l'utilisation non autorisée de la plate-forme.


4 067195-303
Française



5 005223-903



6 101210-000




CE UpRight Inc.
1775 PARK ST. SELMA CALIFORNIA 93662 USA


Model: _____ Serial number: _____
Machine weight: _____ kg Mfg. date: _____
Maxim um wheel load: _____ kg
Maxim um allo wable incline of machine when elevat ed: _____ deg.
Occupants and equipment m ust not exceed the rated maxim um load: _____ kg Maxim um platf orm occupants: _____
Maxim um allo wable side force on platf orm: _____ N
Maxim um platf orm height: _____ m
Maxim um platf orm reach: _____ m
Maxim um allo wable wind speed: _____ m/s-Beauf ort scale
Maxim um hydraulic system pressure: _____ bar
Maxim um system v oltag e: _____ Vdc
This machine is manufactured to compl y with Machinery directive 89-392/CEE

CAUTION: CONSULT OPERATOR'S MANUAL BEFORE USE.


14 061205-003




15 066550-015
English




16 066557-971
UL25




16 066557-959
UL32, UL40



18 101208-002




19 066551-905




20 069338-900




21 064936-099



23 062840-900




24 030768-002



25 066550-215
Deutsch




26 066550-315
Française



27 062466-902

Figure 9: Safety Labels Locations



SPECIFICATIONS

ITEM	UL 25	UL 32	UL 40
Platform Capacity	159 kg (350 lbs.)	136 kg (300 lbs.)	136 kg (300 lbs.)
Max. No. of occupants	1 person	1 person	1 person
Height			
Working Height	9,62 m (31.6 ft.)	11,75 m (38.5 ft.)	14,19 m (46.6 ft.)
Max. Platform Height	7,62 m (25 ft.)	9,75 m (32 ft.)	12,19 m (40 ft.)
Min. Platform Height	38 cm (15 in.)	38 cm (15 in.)	38 cm (15 in.)
Dimensions			
Overall Weight	345 kg (760 lbs.)	390 kg (860 lbs.)	422 kg (930 lbs.)
DC Option Weight	29 kg (64 lbs.)	29 kg (64 lbs.)	29 kg (64 lbs.)
Overall Width (outriggers extended)	1,5 m (59 in.)	2,06 m (81 in.)	2,34 m (92 in.)
Overall Length (outriggers extended)	1,42 m (56 in.)	1,98 m (78 in.)	2,26 m (89 in.)
Stowed Dimensions			
Vertical Height	1,98 m (78 in.)	2,44 m (96 in.)	2,84 m (112 in.)
Width	74 cm (29 in.)	74 cm (29 in.)	74 cm (29 in.)
Depth	1,24 m (49 in.)	1,24 m (49 in.)	1,24 m (49 in.)
Diagonal Storage Height	N/A	1,98 m (78 in.)	1,98 m (78 in.)
Diagonal Storage Length	N/A	2,53 m (99.5 in.)	2,9m (114 in.)
System Voltage	120 VAC 60 Hz or 220 VAC 50/60 Hz		
AC Electric Motor	120 VAC 60 Hz or 220 VAC 50/60 Hz		
DC Electric Power Source	1 - 12 Volt Battery, Group 27 105 Amp/Hrs., Minimum Weight 22 kg (48 lbs.)		
Battery Charger	Automatic, 120 VAC 60 Hz or 220 VAC 50 Hz Output: 10 Amp, 12 Volts DC		
Hydraulic Tank Capacity	5,7 liter (1.5 gal.)		
Maximum Hydraulic Pressure	165 bar(2400 PSI)		
Hydraulic Fluid			
Normal Temperature: above 0° C [32° F]	ISO #46		
Low Temperature: below 0° C [32° F]	ISO #32		
Extreme Temperature: below -17° C [0° F]	ISO #15		
Control System	Push Button Lift and Lower, Red Mushroom EMERGENCY STOP Switch		
Guardrails	1,1 m (43.5 in.) High		
Noise Level			

*Specifications are subject to change without notice. Hot weather or heavy use may affect performance.

Refer to the Service Manual for complete parts and service information.

The UL25/32/40 meets or exceeds all applicable CE and GS machinery directive requirements.

2.0 Introduction

This section contains instructions for the maintenance of the UL-Series Lifts. Procedures for the operational check-out adjustment, scheduled maintenance, and repair/removal are included.

Referring to the *Operator Manual* will aid in understanding the operation and function of the various components and systems of the UL-Series Lifts and help in diagnosing and repair of the machine.

SPECIAL TOOLS

The following is a list of special tools that are required to perform certain maintenance procedures. These tools may be purchased from your dealer.

Description	Part Number
Spanner Wrench For UL25,32,40	062521-010
Strap Wrench	062482-000
Tie Rod Tensioner (2 req'd.)	062738-000
Tensioner Bracket (2 req'd.)	062739-000

2.1 Preventative Maintenance (Table 2-1)

The complete inspection consists of periodic visual and operational checks, together with all necessary adjustments to assure proper performance. Daily inspection will prevent abnormal wear and prolong the life of all systems. The inspection and maintenance schedule is to be performed at regular intervals. Inspection and maintenance shall be performed by personnel who are trained and familiar with mechanical and electrical procedures. Complete descriptions of the procedures are in the text following the table.

 WARNING 	
Before performing preventative maintenance, familiarize yourself with the operation of the machine.	
Never enter the area below the Platform when the Platform is elevated.	

The Preventative Maintenance Table has been designed to be used for machine service and maintenance repair.

Please copy the following page and use the Preventative Maintenance Table as a checklist when inspecting a machine for service.

Preventative Maintenance Table Key

Interval

Daily=each shift or every day
 30d=every month or 30 days
 3m=every 3 months
 1y=every year

Y=Yes/Acceptable

N=No/Not Acceptable

R=Repaired/Acceptable

Preventative Maintenance Report

Date: _____

Owner: _____

Model No: _____ Serial No: _____

Serviced By: _____

Service Interval: _____

Table 2-1: Preventative Maintenance

COMPONENT	INSPECTION OR SERVICES	INTERVAL	Y	N	R
Battery System (DC Units only)	Check electrolyte level	Daily			
	Check battery cable condition	Daily			
	Charge batteries	Daily			
	Check charger condition & operation	Daily			
	Check specific gravity	30d			
	Clean exterior	3m			
Hydraulic Oil	Clean terminals	3m			
	Check oil level	Daily			
Hydraulic System	Drain and replace oil (ISO #46)	1y			
	Check for leaks	Daily			
	Check line connections	30d			
Emergency Hydraulic System	Check for exterior wear	30d			
	Open the emergency lowering valve and check for serviceability	Daily			
Emergency Down	Check procedure for Emergency Down batteries	3m			
Hydraulic Pump	Check for fitting leaks	Daily			
	Wipe clean	30d			
	Check for leaks at mating surfaces	30d			
	Check mounting bolts for proper torque	30d			
Controls	Check condition & operation	Daily			
Control Cable	Check the exterior of the cable for pinching, binding or wear	Daily			
Platform Deck and Rails	Check fasteners for proper torque	Daily			
	Check welds for cracks	Daily			
	Check condition of deck	Daily			
Elevating Assembly	Check entry way closure	Daily			
	Inspect for external damage, dents, loose rivets or cracks	Daily			
	Check chains and sheaves for wear	3m			
Chassis	Inspect and adjust sequence straps	30d			
	Check cables for pinch or rubbing points	Daily			
	Check welds for cracks	Daily			
	Check casters for damage	Daily			
Lift Cylinder	Check component mounting for proper torque	3m			
	Check for leaks	Daily			
Entire Unit	Check fitting for proper torque	30d			
	Perform pre-operation inspection	Daily			
	Check for and repair collision damage	Daily			
	Lubricate	3m			
	Check fasteners for proper torque	3m			
Labels	Check for corrosion; remove and repaint	3m			
	Check for peeling, missing, or unreadable labels & replace	Daily			

2.2 Lubrication

Refer to Figure 2-1 for location of items that require lubrication service. Use an aerosol chain lubricant for all components to be lubricated that require oil.

CASTERS

Using a grease gun, apply 1 or 2 shots of multi-purpose bearing grease to each zerk fitting. Swivel casters have two zerk fittings, one at the wheel bearing and one at the swivel.

CHAINS

1. Ensure that Platform is fully lowered.
2. Apply enough aerosol chain lubricant to exposed section of chain to allow lubricant to run down chain.

SCREW JACKS

Apply a moderate amount of aerosol chain lubricant to each screwjack assembly.




Figure 2-1: Lubrication




Figure 2-2: Hydraulic Power Unit

HYDRAULIC OIL RESERVOIR (Figure 2-2)

Verify that Platform is fully lowered.

1. Remove hydraulic reservoir from pump by removing four screws and four grip plates.
2. Provide a suitable container (reservoir has a 5,7 liter [1.5 U.S. gal.] capacity) and dispose of hydraulic fluid properly; contact your local oil recycler.

Note: Ensure o-ring is in place on pump when installing hydraulic reservoir.

3. Reinstall hydraulic reservoir to pump assembly with grip plates and screws.
4. Fill hydraulic reservoir through the dipstick hole with ISO #46 hydraulic fluid. Hydraulic reservoir has a 5,7 liter [1.5 U.S. gal.] capacity.

2.3 Battery Maintenance (DC units only)

Electrical energy for the motor is supplied by a 12-volt battery. Proper care and maintenance of the battery and motor will ensure maximum performance from the lift.

WARNING

Hazard of explosive gas mixture. Keep sparks, flame and smoking materials away from batteries.

Always wear safety glasses when working with batteries.

Battery fluid is highly corrosive. Rinse away any spilled fluid thoroughly with clear water.

BATTERY INSPECTION AND CLEANING

Check battery fluid level daily, especially if work platform is being used in a warm, dry climate. If required, add distilled water only; use of tap water with high mineral content will shorten battery life.

WARNING

If battery water level is not maintained, battery will not fully charge, creating a low discharge rate which will damage Motor/Pump unit and void warranty.

Battery should be inspected periodically for signs of cracks in the cases, electrolyte leakage and corrosion of the terminals. Inspect cables for worn spots or breaks in the insulation and for broken cable terminals.

Clean battery that shows signs of corrosion at the terminals or onto which electrolyte has overflowed during charging. Use a baking soda solution to clean the battery, taking care not to get the solution inside the cells. Rinse thoroughly with clear water. Clean battery and cable contact surfaces to a bright metal finish whenever a cable is removed.

BATTERY CHARGING (Figure 2-3)

Charge battery at end of each work shift or sooner if battery has been discharged.

CAUTION

Charge battery in a well-ventilated area.

Do not charge battery when the lift is in an area containing sparks or flames.

Permanent damage to battery will result if battery is not immediately recharged after discharging.

Never leave charger operating unattended for more than two days.

Never disconnect cables from battery when charger is operating.

Keep charger dry.

When night air temperatures fall below 18°C (65°F) a battery charged in an unheated area should be placed on charger as soon after use as possible. Under such conditions a 4 hour equalize charge once a week in the early afternoon will improve state of charge and battery life.

1. Check battery fluid level. If electrolyte level is lower than 10 mm ($\frac{3}{8}$ in.) above plates add distilled water only.
2. Verify charger voltage switch is set to 12 volts.
3. The battery charger is located at the rear of the mast. Connect extension cord (1,5 mm² [12 gauge] conductor minimum and 15 m [50 ft.] in length maximum) to the charger plug. Connect other end of extension cord to properly grounded outlet of proper voltage and frequency.
4. Set charger control to "conventional" setting. Charger ammeter should indicate charge rate.
5. When battery is fully charged, charger automatically turns itself off. Disconnect extension cord.

BATTERY CELL EQUALIZATION

The specific gravity of the electrolyte in the battery cells should be equalized monthly. To do this, charge batteries as outlined in Battery Charging. After this initial charge, check the electrolyte level in all cells and add distilled water as necessary. Then, turn the charger on for an additional eight hours. During this time, the charging current will be low (four amps) as cells are equalizing.

After equalization, the specific gravity of all cells should be checked with a hydrometer. The temperature corrected specific gravity in this state should be 1.260. If any corrected readings are below 1.230, the battery should be replaced.

Do not check the specific gravity in a cell to which water has just been added. If there is not enough electrolyte in a fully charged cell to obtain a sample for the hydrometer, add water and continue charging for one to two hours to adequately mix the water and electrolyte.




Figure 2-3: Battery Charger

2.4 Setting System Relief Valve (Figure 2-4)

Check the hydraulic system pressure whenever the pump or relief valve has been serviced or replaced.

⚠	WARNING	⚠
<p>The hydraulic oil may be of sufficient temperature to cause burns. Wear safety gloves and safety glasses when handling hot oil.</p>		

1. Install outriggers and level unit as normal, (see Operator Manual 3 for operating instructions), and operate the hydraulic system for 5-10 minutes to warm the hydraulic oil.
2. Remove Cover from Power Unit Assembly
3. Place rated load on the platform (see table 1-1 for specifications). **Do Not** use live weight for this procedure.
4. Install pressure gauge on gauge port.
5. Remove the cap from the System Relief Valve (fig. 2-4), and turn the adjustment screw counterclockwise two full turns.
6. Operate controls to elevate machine. (Machine will not raise until Relief Valve is properly adjusted.)
7. Turn the System Relief Valve Clockwise (fig. 2-4) until the machine begins to rise.
8. Elevate the platform fully and verify that the pressure does not exceed 165 bar (2400 PSI) at any time during the lift cycle.
9. Replace cap on System Relief Valve, reassemble Cover.




Figure 2-4: System Relief Valve

2.5 Mast Assembly (Figure 2-6,2-7) Disassembly

Using a suitable lifting device, lower the work platform into a horizontal position (Figure 2-5). If possible, place the machine onto a sturdy work table using a forklift.



WARNING



Never attempt to lower lift into a horizontal position without the use of a suitable lifting device; bodily injury or damage to the machine may result.

NOTE: Mark all components as they are removed so they can be reinstalled in the correct sequence and location.

Platform Assembly Removal (Figure 2-6)

1. Extend elevating assembly far enough to expose the eight screws attaching the cage support assembly to stage 6 by opening the emergency lowering valve and pulling on the cage guardrail.
2. Remove cover from front of platform assembly.




Figure 2-5: Lifting/Lowering UL Lift

3. Remove cotter pins, and drive out chain retaining pins from the top front of stage 5.
4. Loosen screws from strap retainer on stage 5 top casting. Pull strap free of retainer.
5. Remove cage support screws, slide the cage support out of the sixth stage mast and set aside. It should not be necessary to remove the pinch shield. Be careful not to damage the control cable.

Note: to remove the platform assembly from the cage support assembly, follow steps 6-10 below.

6. Remove cable sheaves from cage support weldment, and strain reliefs from stage 5 top casting.
7. Loosen screws from strap retainer on platform assembly weldment and free strap from retainer.
8. Remove two screws and washers holding stop bracket located at top of platform assembly weldment. Remove the stop bracket.
9. Slide the cage support weldment out of the top of the platform assembly weldment.
10. Slide bearings in platform assembly may now be inspected / replaced if necessary.

#6 Mast

1. Remove sequence strap retainer on the top of #4 mast.
2. Remove the Allen head screws holding the top mast bearings between the #5 and #6 mast. Remove the top mast bearings.
3. Slide #6 mast out of #5 mast. As mast is removed, the bottom four mast bearings will fall out; note their orientation for re-assembly.
4. Disconnect chain from top of #4 mast.

#5 Mast

1. Remove sequence strap retainer on the top of #3 mast.
2. Remove the Allen head screws holding the top mast bearings between the #4 and #5 mast. Remove the top mast bearings.
3. Slide #5 mast out of #4 mast. As mast is removed, the bottom four mast bearings will fall out; note their orientation for re-assembly.
4. Disconnect chain from top of #3 mast.

#4 Mast

1. Remove sequence strap retainer on the top of #2 mast.
2. Remove the Allen head screws holding the top mast bearings between the #3 and #4 mast. Remove the top mast bearings.
3. Slide #4 mast out of #3 mast. As mast is removed, the bottom four mast bearings will fall out; note their orientation for re-assembly.




Figure 2-6: Mast Assembly, Strap and Chain Detail




Figure 2-7: Mast Assembly, Bearing Detail

2.5 Mast Assembly (Cont.)

4. Disconnect chain from top of #2 mast.
5. Remove cylinder by following instructions in *Section 2.7*.

#3 Mast

1. Remove sequence strap retainer on the top of #1 mast.
2. Remove the Allen head screws holding the top mast bearings between the #2 and #3 mast. Remove the top mast bearings.
3. Slide #3 mast out of #2 mast. As mast is removed, the bottom four mast bearings will fall out; note their orientation for re-assembly.

#2 Mast

1. Remove the Allen head screws holding the top mast bearings between the #1 and #2 mast. Remove the top mast bearings.
2. Slide #2 mast out of #1 mast. As mast is removed, the bottom four mast bearings will fall out; note their orientation for re-assembly.

ASSEMBLY (Figure 2-7)

Note: Use **WD-40** lubricant as necessary to aid in reassembly.

#2 Mast

1. Set #2 mast in place.
2. Install bottom lower bearings.
3. Install bottom upper bearings.
4. Slide #2 mast in all the way except 30 -38 cm (12-15").
5. Install top bearings and secure with retaining screws using Loctite® 242 or equivalent on the threads.
6. Slide #2 mast in completely.

#3 Mast

1. Set #3 mast in place with the sequencing strap inside.
2. Install bottom lower bearings.
3. Install bottom upper bearings.
4. Slide #3 mast in all the way except 30 -38 cm (12-15").
5. Install top bearings and secure with retaining screws using Loctite® 242 or equivalent on the threads.
6. Place a 10" (25 cm) long wood block between #3 and #2 masts, slide #3 mast down tight against block. Pull sequencing strap completely out of the bottom of assembly.
7. Install cylinder assembly by following instructions in section 2.6.

#4 Mast

1. Set #4 mast in place with the sequencing strap inside and the chains on the bottom.
2. Install bottom lower bearings.
3. Install bottom upper bearings.
4. Slide mast #4 in, make sure chains are not twisted.
5. Install top bearings and secure with retaining screws using Loctite® 242 or equivalent on the threads.
6. Install chains around #3 sheave and down through #3 casting, secure to #2 casting with new roll pins.
7. Use a center punch to dimple pin hole after roll pins are installed.

#5 Mast

1. Set #5 mast in place with the sequencing strap inside.
2. Install bottom lower bearings.
3. Install bottom upper bearings.
4. Slide #5 mast in, make sure chains are not twisted.
5. Install top bearings and secure with retaining screws using Loctite® 242 or equivalent on the threads.
6. Install chains around #4 sheaves and down through #4 casting, secure to #3 casting with new roll pins.
7. Use a center punch to dimple pin holes after all roll pins are installed.
8. Slide mast in, leaving 25 cm (10") exposed.

#6 Mast

1. Set #6 mast in place with the sequencing strap inside.
2. Run the remaining sequencing strap (from platform assembly) through the slot in the bottom of stage #6 and up through the inside. Leave just enough slack on the outside to reach the attachment point at the top of stage #5.
3. Install bottom lower bearings.
4. Install bottom upper bearings.
5. Slide #6 mast in, make sure chains are not twisted.
6. Install top bearings and secure with retaining screws using Loctite® 242 or equivalent on the threads.
7. Install #6 chain around #5 sheave and through casting, secure to #4 casting with new roll pins.
8. Use a center punch to dimple pin holes after all roll pins are installed.
9. Pull the sequencing strap attached to the bottom of mast #6 out through the bottom of the mast assembly. Be sure not to pull the strap that is attached to the top of mast #5.

2.5 Mast Assembly (Cont.)

Platform Support Assembly

1. Slide cage support weldment into the top of the platform assembly weldment.
2. Install stop bracket and retaining screws / washers.
3. Feed chains over sheave.
4. Install cable sheaves with cables to the top of cage support weldment.
5. Feed sequencing strap from inside mast #6 over sheave and out through the slot in the top of the cage support weldment.
6. Install cage support weldment to mast #6 using eight screws, tighten.
7. Attach chains to #5 casting front using new cotter pins.

Sequencing Strap Installation

When installing straps, make sure they are not twisted.

1. Feed fish tape up through the bottom slot in cage support weldment and out through the top slot.
2. Attach strap to fish tape and pull out through bottom slot.
3. Feed fish tape down through the opening in the front of the platform support weldment and out through the bottom of the platform support weldment.
4. Attach strap to fish tape and pull out through opening. Attach strap to platform support weldment, pull tightly and secure with strap clamp and screws using Loctite® 242 or equivalent on the threads.
5. Fish #6 strap up through mast between fourth and fifth stages with fish tape.
6. Fish #5 strap up through mast between third and fourth stages with fish tape.
7. Fish #4 strap up through mast between third and second stages with fish tape.
8. Fish #3 strap up through mast between first and second stages with fish tape.
9. Install strap #6 to #4 top casting.
10. Install strap #5 to #3 top casting.
11. Install strap #4 to #2 top casting.
12. Install strap #3 to top of #1 mast weldment.
13. Install the strap clamps and retaining screws using Loctite® 242 or equivalent on the threads. Pull straps tight while tightening retaining screws.

2.6 Cylinder Assembly

SEAL REPLACEMENT (Figure 2-8)

Note: The Lift Cylinder Seal can be accessed from the bottom of the Lift without removing the Cylinder Assembly.

Using a suitable lifting device, lower the work platform into a horizontal position (Figure 2-5). If possible, place the machine onto a sturdy work table using a forklift.

	WARNING	
---	----------------	---

<p>Never attempt to lower lift into a horizontal position without the use of a suitable lifting device; bodily injury or damage to the machine may result.</p>
--

1. Remove cylinder mounting plate fasteners and retaining ring.
2. Remove tie rod nuts, count the number of turns required to bring the nut flush with the tie rod end and record for reference during installation. The tension on the tie rods maintains the left / right positioning of the cylinder within the mast assembly, reinstalling the nuts with the proper tension will speed up adjustment later.
3. Remove the cylinder mounting plate. Be careful not to allow the tie rods to suck back inside of the mast assembly, replace the nuts on the tie rod ends temporarily to prevent this.
4. Remove hydraulic line from the cylinder fitting and cap the cylinder fitting to prevent contaminants from entering the cylinder.

	CAUTION	
---	----------------	---

<p>Marring the surface of the cylinder rod will damage cylinder seals and cause leakage. Use a strap wrench to prevent rod damage.</p>
--

5. Extend cylinder rod at least twelve inches by hand. Apply heat to rod near end cap to loosen Loc-tite®.

	WARNING	
---	----------------	---

<p>Wear safety glasses and heat resistant gloves when operating torch. Do not touch hot surfaces without proper protection.</p>

6. Using a Strap Wrench, 062482-000, to secure the cylinder rod, unscrew the cylinder rod end. If necessary, thread a 9/16 x 18 bolt into end cap port to use as a lever. Remove rod end cap and orifice / bleeder tube assembly.

7. Remove the seal retainer, using the spanner wrench, 062521-010.
8. Clean all sealing surfaces with solvent. Inspect cylinder rod for excessive wear, replace if necessary.
9. Remove all seals from seal retainer, rod end cap and discard.

Note: Apply clean hydraulic fluid to new cylinder seal, threads and all sliding surfaces prior to assembly. If necessary, soften new seals with warm water (82°C [180°F]) to aid in installation.

10. Twist the pressure seal into a 'C' shape and snap into seal groove in seal retainer, making sure the lip of the seal is facing inward.
11. Using the same method, install the rod wiper into the seal retainer outer groove, making sure that the blade of the seal is facing outward from the seal retainer.
12. Replace static seals in rod end cap and seal retainer by stretching them into place. Be careful not to cut the seal during installation.
13. Install the seal retainer onto rod using a sharp blow from a hard rubber mallet to overcome seal squeeze. Slide seal retainer into place and tighten using the spanner wrench.

14. Rod and rod end threads must be absolutely clean. Spray threads with Loctite® primer #7471, allow to dry for five minutes. Coat threads liberally with Loctite® #242. Thread rod end cap onto rod, tighten using strap wrench to hold rod.
15. Push rod back into cylinder for reassembly.
16. Reconnect hydraulic line.
17. Remove nuts from tie rod ends and set the cylinder mounting plate into place. Secure mounting plate with fasteners.
18. Install tie rod nuts flush with tie rod ends, torque each nut the exact number of turns used to remove it.
19. Reinstall retaining ring.
20. Using a suitable lifting device, raise the lift to its normal vertical position.
22. Bleed air from cylinder by cycling the mast to full extension several times. The cylinder is self bleeding; air will be forced out of the cylinder during the lowering cycle.
23. If necessary, remove pinch shield and check alignment of cylinder within mast assembly by peering down the mast with a flashlight. The cylinder may be moved left or right by tightening one or the other of the tie rod nuts.




Figure 2-8: lift Cylinder

⚠ CAUTION ⚠

If cylinder is not centered, mast may "hang" when lowering.

⚠ WARNING ⚠

Keep hands clear of the mast assembly when the pinch shield is removed for inspection purposes; pinching injury to hands may result .

Never operate a machine with the pinch shield removed, except for inspection.

2.6 Cylinder Assembly (Cont.)

ORIFICE VALVE CLEANING

Using a suitable lifting device, lower the work platform into a horizontal position (Figure 2-5). If possible, place the machine onto a sturdy work table using a forklift.

 WARNING 
<p>Never attempt to lower lift into a horizontal position without the use of a suitable lifting device; bodily injury or damage to the machine may result.</p>

1. Remove cylinder mounting plate fasteners and retaining ring.
2. Remove tie rod nuts, count the number of turns required to bring the nut flush with the tie rod end and record for reference during installation. The tension on the tie rods maintains the left / right positioning of the cylinder within the mast assembly, reinstalling the nuts with the proper tension will speed up adjustment later.
3. Remove the cylinder mounting plate. Be careful not to allow the tie rods to suck back inside of the mast assembly, replace the nuts on the tie rod ends temporarily to prevent this.
4. Remove hydraulic line from the cylinder fitting and cap the cylinder fitting to prevent contaminants from entering the cylinder.

 CAUTION 
<p>Marring the surface of the cylinder rod will damage cylinder seals and cause leakage. Use a strap wrench to prevent rod damage.</p>

5. Extend cylinder rod at least twelve inches by hand. Apply heat to rod near end cap to loosen Loc-tite®.

 WARNING 
<p>Wear safety glasses and heat resistant gloves when operating torch. Do not touch hot surfaces without proper protection.</p>

6. Using a Strap Wrench, 062482-000, to secure the cylinder rod, unscrew the cylinder rod end. If necessary, thread a 9/16 x 18 bolt into end cap port to use as a lever. Remove rod end cap and orifice / bleeder tube assembly.
7. Remove snap ring to release orifice / bleeder tube from rod end cap.

8. Clean orifice valve hole with a straight pin. Flush with solvent to remove any contamination that may remain in bleeder tube.
9. Reinstall orifice / bleeder tube into rod end cap and secure with snap ring.
10. Replace static seal on red end. Existing seal may have been damaged by heating rod.
11. Rod and rod end threads must be absolutely clean. Spray threads with Loctite® primer #7471, allow to dry for five minutes. Coat threads liberally with Loctite® #242. Thread rod end cap onto rod, tighten using strap wrench to hold rod.
12. Push rod back into cylinder for reassembly.
13. Reconnect hydraulic line.
14. Remove nuts from tie rod ends and set the cylinder mounting plate into place. Secure mounting plate with fasteners.
15. Install tie rod nuts flush with tie rod ends, torque each nut the exact number of turns used to remove it.
16. Reinstall retaining ring.
17. Using a suitable lifting device, raise the lift to its normal vertical position.
18. Bleed air from cylinder by cycling the mast to full extension several times. The cylinder is self bleeding; air will be forced out of the cylinder during the lowering cycle.
19. If necessary, remove pinch shield and check alignment of cylinder within mast assembly by peering down the mast with a flashlight. The cylinder guide bearings must not be touching the inside surface of #6 mast. The cylinder may be moved left or right by tightening the left or right tie rod nuts respectively.

 CAUTION 
<p>If cylinder is not centered, mast may "hang" when lowering.</p>

 WARNING 
<p>Keep hands clear of the mast assembly when the pinch shield is removed for inspection purposes; pinching injury to hands may result .</p> <p>Never operate a machine with the pinch shield removed, except for inspection.</p>




Figure 2-9: Cylinder Assembly Installation

CYLINDER REMOVAL (Figure 2-9)

Using a suitable lifting device, lower the work platform into a horizontal position (Figure 2-5). If possible, place the machine onto a sturdy work table using a forklift.

WARNING

Never attempt to lower lift into a horizontal position without the use of a suitable lifting device; bodily injury or damage to the machine may result.

1. Remove cylinder mounting plate fasteners and retaining ring.
2. Remove tie rod nuts, count the number of turns required to bring the nut flush with the tie rod end and record for reference during installation. The tension on the tie rods maintains the left / right positioning of the cylinder within the mast assembly, reinstalling the nuts with the proper tension will speed up adjustment later.
3. Remove the cylinder mounting plate. Be careful not to allow the tie rods to suck back inside of the mast assembly, replace the nuts on the tie rod ends temporarily to prevent this.
4. Remove hydraulic line from the cylinder fitting and cap the cylinder fitting to prevent contaminants from entering the cylinder.
5. Remove sequence strap retainers on the top of #3 and #2 masts.
6. Remove front and rear mast access plates from the bottom of the #1 mast.

7. Remove the screws and washers, attaching the #2 and #3 bottom castings to the #2 and #3 mast assemblies.
8. While keeping tension on the tie rods, slide the cylinder and #2 and #3 bottom castings out the bottom of the UL Lift far enough to expose both castings.
9. Install cylinder Tensioner Brackets, 062739-000 on #2 and #3 bottom castings. Remove tie rod nuts and install the Tie Rod Tensioners, 062738-000. Remove all slack from the chains with the Tie Rod Tensioners.
10. Remove cylinder assembly from mast assembly.

INSTALLATION

NOTE: Cylinder assembly must have Tension Brackets, Tensioner Spacer and Tie Rod Tensioners installed to remove slack from chain.

1. Slide cylinder assembly into mast assembly until #3 bottom casting is at the bottom of the mast assembly.
2. Install the screws and washers attaching the #3 bottom casting to the #3 mast assembly.
3. Remove cylinder Tensioner Brackets from #2 and #3 bottom castings and Tie Rod Tensioners from tie rods. Install tie rod nuts finger tight.
4. While maintaining tension on the tie rods to keep slack out of the chains, slide cylinder assembly completely into the mast assembly.
5. Install the screws and washers attaching the #2 bottom casting to the #2 mast assembly.
6. Install front and rear mast cover plates on the bottom of #1 mast.
7. Fish #4 strap between #3 and #2 mast with fish tape.
8. Slide #4 strap through #2 casting.
9. Fish #3 strap between #2 and #1 mast with fish tape.
10. Install strap #4 to #2 top casting.
11. Install strap #3 to #1 top casting.
12. While maintaining tension on the sequencing straps, install strap retainers using Loctite® 242 or equivalent on the threads of the retainer screws.
13. Reconnect hydraulic line.
14. Remove nuts from tie rod ends and set the cylinder mounting plate into place. Secure mounting plate with fasteners.
15. Install tie rod nuts flush with tie rod ends, torque each nut the exact number of turns used to remove it.
16. Reinstall retaining ring.

2.6 Cylinder Assembly (Cont.)

INSTALLATION (CONT.)

17. Using a suitable lifting device, raise the lift to its normal vertical position.
18. Bleed air from cylinder by cycling the mast to full extension several times. The cylinder is self bleeding; air will be forced out of the cylinder during the lowering cycle.
19. If necessary, remove pinch shield and check alignment of cylinder within mast assembly by peering down the mast with a flashlight. The cylinder guide bearings must not be touching the inside surface of #6 mast. The cylinder may be moved left or right by tightening the left or right tie rod nuts respectively.



WARNING



Keep hands clear of the mast assembly when the pinch shield is removed for inspection purposes; pinching injury to hands may result.

Never operate a machine with the pinch shield removed, except for inspection.

2.7 Torque Specifications

HYDRAULIC COMPONENTS

Use the following values to torque hydraulic components used on UpRight Work Platforms.

Note: Always lubricate threads with clean hydraulic oil prior to installation.

Table 2-2: Hydraulic Component Torque

TYPE: SAE PART SERIES	CARTRIDGE POPPET		FITTINGS		HOSES	
	(Ft/Lbs)	(Nm)	(Ft/Lbs)	(Nm)	(In/Lbs)	(Nm)
#4	N/A	N/A	N/A	N/A	135-145	15-16
#6	N/A	N/A	10-20	14-27	215-245	24-28
#8	25-30	34-41	25-30	34-41	430-470	49-53
#10	35-40	47-54	35-40	47-54	680-750	77-85
#12	85-90	115-122	85-90	115-122	950-1050	107-131
#16	130-140	176-190	130-140	176-190	1300-1368	147-155

Coil nuts: 3 Nm (30 In/Lbs)

FASTENERS

Use the following values to torque fasteners used on UpRight Work Platforms unless a specific torque value is called out for the part being installed.

Table 2-3: Bolt Torque

THREAD SIZE <small>American National Standard-UNF (fine)</small>	WIDTH ACROSS FLATS	TORQUE VALUE			
		ENGLISH		METRIC	
1/4	7/16	110	In/Lbs	12	Nm
5/16	1/2	190	In/Lbs	22	Nm
3/8	9/16	30	Ft/Lbs	41	Nm
7/16	5/8	50	Ft/Lbs	68	Nm
1/2	3/4	75	Ft/Lbs	102	Nm
5/8	15/16	150	Ft/Lbs	203	Nm
3/4	1 1/8	250	Ft/Lbs	339	Nm
7/8	1 5/16	400	Ft/Lbs	542	Nm
1	1 1/2	600	Ft/Lbs	813	Nm

3.0 Introduction

Table 3-1 provides a logical sequence of tests that are designed to isolate problems with the UpRight Lift. This table includes a list of probable causes and remedies.



WARNING



When troubleshooting, ensure that the work platform is resting on a firm, level surface.

When performing any service which requires the Platform to be raised, ensure that all four (4) outriggers are properly installed.

Unplug the machine or disconnect the battery when replacing or testing the continuity of any electrical component.

GENERAL PROCEDURE

Troubleshooting should be carried out in two steps. First, thoroughly study both hydraulic and electric schematics to determine possible causes. Loose terminal connections and short circuits are always a potential cause when troubleshooting. Second, check suspect components electrically, hydraulically and mechanically to determine if they are at fault. Refer to Tables 4-1 and 4-2 for Reference Designations used in Table 3-1.

Table 3-1: Troubleshooting

TROUBLE	PROBABLE CAUSE	REMEDY
Lift Function inoperable, electric motor does not start.	<ol style="list-style-type: none"> 1. Extension cord too long or insufficient capacity. 2. Not plugged in or faulty connection (AC only). 3. No power at wall outlet (AC only). 4. Faulty Battery Charger (DC only). 5. Faulty Battery (BAT). 6. Key Switch (S2), Emergency Stop Switch (S1, S3) or Push-button Switch (S4, S5) failed open. 7. Outrigger Interlock Switch (S7,S8, 9,S10). 8. Open circuit in cable to motor control box. 9. Faulty Electric Motor (M1). 	<p>Use minimum 1,5 mm² (12 ga.) cord of 16m (50 feet) or less in length.</p> <p>Check all AC plugs and cords used.</p> <p>Check power output at wall outlet.</p> <p>Check the voltage output of the Battery Charger. If less than 12 VDC, repair or replace.</p> <p>After completely charging Battery, test Battery. Replace as required.</p> <p>With the switch in the ON position, check continuity across the contacts. If none, replace.</p> <p>Make sure all four outriggers are in firm contact with floor. Check continuity of interlock switches.</p> <p>Test for continuity through cable assembly and repair or replace.</p> <p>While operating the Lift function, check the voltage to the Electric Motor. If voltage is present (12VDC or 120/240VAC), replace the motor. In case of low AC voltage, see #1.</p>
Lift turns on and off repeatedly.	<ol style="list-style-type: none"> 1. Low line voltage or battery charge. 	Use minimum 11,5 mm ² (12 ga.) cord of 16m (50 feet) or less in length.
One or more, but not all indicator lights fail to operate	<ol style="list-style-type: none"> 1. Indicator light damaged or faulty. 2. Outrigger limit switch damaged or faulty. 3. Chassis harness damaged or improperly connected. 	<p>Replace indicator light.</p> <p>Replace switch.</p> <p>Repair damage, insure proper connection.</p>
Lift function inoperable, Electric Motor starts when control is activated.	<ol style="list-style-type: none"> 1. Emergency Lowering Valve (V2) open. 2. Hydraulic Reservoir Low. 3. Down Valve (V2) stuck. 4. Relief Valve (RV) out of adjustment or faulty. 5. Lift Valve (V1) faulty. 6. Faulty Hydraulic Pump (P). 	<p>Close valve.</p> <p>Check hydraulic fluid level, top off as required.</p> <p>Check or replace Down Valve (V2).</p> <p>Adjust the Relief Valve (RV). If not adjustable, replace.</p> <p>Check or replace Lift Valve (V1).</p> <p>Check pressure and delivery of the Hydraulic Pump. Replace if required.</p>

TROUBLE	PROBABLE CAUSE	REMEDY
Platform does not lower using electrical switches. (Will lower using emergency lowering valve.)	<ol style="list-style-type: none"> 1. Down Valve Solenoid (SOL1) faulty. 2. Electrical malfunction. 	<p>Test for continuity across Solenoid. Repair or replace.</p> <p>Check all AC plugs and cords used (AC only). Check power output at wall outlet (AC only).</p> <p>With each switch (S1,S2,S3,S4,S6) in the ON position, check continuity across the contacts. If none, replace.</p>
Platform does not lower or lowers very slowly.	<ol style="list-style-type: none"> 1. Down Orifice (ORF) plugged. 2. Down Valve (V2) blocked or stuck closed. 2. Mechanical interference. 	<p>Remove and clean Down Orifice check valve.</p> <p>Check function / clear blockage of Down Valve.</p> <p>Inspect Mast Assembly, correct interference.</p>
Platform continues to lower when controls are released.	<ol style="list-style-type: none"> 1. Down Valve (V1) stuck open 	Clean or replace Down Valve.

Table 3-1: Troubleshooting (cont'd)

LIFT DOES NOT TURN ON - AC

All voltages are referenced to Chassis ground. Using a voltmeter, place the negative probe directly to a clean ground source on the AC motor. If equipped with battery back up, remove back up battery before proceeding. Disconnect both chassis connector and coil cord connector. Set voltmeter for DC voltage. Plug lift into outlet.

1) Check for voltage at the power terminals of the circuit board. Turn off key switch and E-Stop switch. Power terminal is S28 and ground terminal is GND. See drawing.

1a) DC voltage at S28 is less than 11 VDC.	a) Extension harness excessive in length. b) Low line voltage. c) Damaged or faulty circuit board.
1b) Voltage is found at the ground terminal.	a) Damaged or faulty motor harness. b) Damaged or faulty circuit board.
1c) Between 11 VDC and 26 VDC found at S28. Zero volts found at GND.	a) Continue to #2.

2) Check for voltage at the terminals of the key switch. Turn the key switch on and the E-Stop switch off.

2a) No voltage is found on either terminal.	a) Circuit board is damaged.
2b) Voltage is found only on one of the two key switch terminals.	a) Ignition key switch is faulty.
2c) Voltage is found at both sides of the key switch.	a) Continue to step 3.

3) Check voltages at the chassis harness. Turn on the ignition key and turn off the E-Stop. Disconnect the chassis harness. Check voltage of pin 6 and pin 1 of chassis connector on the circuit board.

3a) Voltage at pin 6 does not exist or is less than 11 volts DC.	a) Circuit board is damaged.
3b) Voltage at ground pin 1 is not zero.	a) Circuit board is damaged. b) Ground on motor harness damaged or connected improperly.
3c) Voltage at pin 6 is between 10 and 12 VDC, voltage at pin 1 is zero.	a) Continue to step 4.

4) Plug in Chassis harness. Turn on ignition key, turn off E-Stop switch. Check voltages at pin 1 and 6 of the chassis harness. This may require the use of a sharp probe to pierce the insulation of the corresponding wires.

4a) Pin 6 is not between 10 and 12 VDC.	a) Damaged or shorted chassis harness.
4b) Voltage found at pin 1.	a) Circuit board is damaged. b) Ground on motor harness damaged or connected improperly.

LIFT DOES NOT RAISE - AC

1) Plug lift into outlet. Make sure all outriggers are extended and raised. Turn off the E-Stop switch and turn on the ignition key. Wait five seconds for machine to turn on and outrigger lights to light.

1a) Outrigger lights do not turn on.	a) See LIFT DOES NOT TURN ON
1b) Outrigger lights turn on immediately and no five second delay is present.	b) Circuit board is damaged. Replace circuit board.
1c) Fewer than four indicator lights will operate.	a) Indicator light is damaged. b) Chassis harness damaged or incorrectly connected. c) Outrigger limit switch defective or improperly connected.
1d) All four indicator lights turn on five seconds after ignition key is turned on.	a) Continue to step 2.

2) Pull out both E-Stop switches. Activate the common and up switch on the upper control box.

2a) Motor does not run.	a) Continue to step 3.
2b) Motor runs but will not raise.	a) Hydraulic system failure. b) Damaged or improperly connected motor harness. c) Damaged pump solenoid.
2c) Motor attempts to start but machine turns off and then restarts in five seconds.	a) Improperly connected or damaged motor harness. b) Improperly connected or damaged coil cord or upper control box. c) Damaged pump solenoid. d) Extension harness excessive in length. e) Low line voltage. f) Damaged pump motor.

3) Open the lid on the lower control box. Check for voltage at the E-Stop switch. Ignition key is turned on E-Stop is pulled out on both the upper and lower box.

3a) No voltage is present at either of the terminals on the E-Stop.	a) Circuit board is damaged. Replace circuit board.
3b) Voltage is present on both terminals of the E-Stop switch.	a) Check for correct operation of upper E-Stop switch. Continue to step 4.
3c) Voltage is only present at one side of the E-Stop switch.	a) Replace E-Stop switch in whole or in part.

4) Check Circuit board lift circuit. Place voltmeter probe at lift terminal S26 at the upper right hand side of the circuit board. See drawing(Page 3-5). Activate the common and up switch on the upper control box.

4a) When up button is pressed, 10-12 VDC is not present at pin S26.	a) Improperly connected or damaged coil cord or upper control control box. b) Improperly connected or damaged chassis harness. c) Damaged circuit board.
4b) When up button is pressed, 10-12 VDC is present at pin S26.	a) Continue to step 5.

5) Set voltmeter for AC voltage. Place one probe of the voltmeter on -120 and the other probe on motor. See drawing(Page 3-5). Plug the lift into an outlet. Set outriggers, turn on ignition key, and pull out both E-Stops. Press the common and up switches on the upper control box.

5a) Line voltage is found between -120 and motor.	a) Damaged or improperly connected motor harness. b) Damaged motor.
5b) Line voltage is not found between -120 and motor.	a) Circuit board damaged.

LIFT DOES NOT LOWER - AC

1) Lift will raise but will not lower. Turn on key switch, pull out both upper and lower E-Stops. Press the common and down push buttons on the upper control box.

1a) Lift turns off and restarts in five seconds.	a) Low line voltage. b) Extension harness excessive in length. c) Improperly connected or damaged motor harness. d) Improperly connected or damaged coil cord or upper control box. e) Damaged down solenoid.
1b) Outrigger lights turn on immediately and no five second delay is present.	a) Continue to step 2.

Troubleshooting

Table 3-1: Troubleshooting (cont'd)

2) Check circuit board for correct output. Open the lid on the lower control box. Using a voltmeter, check the voltage terminal S27 found on the upper right hand side of the circuit board. See drawing. Turn on ignition key and pull out both E-Stop switches. Depress the common and down switches on the upper control box.

2a) Motor does not run.	Continue to step 3.
2b) Motor runs but will not raise.	a) Hydraulic system failure. b) Damaged or improperly connected motor harness. c) Damaged pump solenoid.
2c) Motor attempts to start but machine turns off and then restarts in five seconds.	a) Improperly connected or damaged motor harness. b) Improperly connected or damaged coil cord or upper control box. c) Damaged pump solenoid. d) Extension harness excessive in length. e) Low line voltage. f) Damaged pump motor.

LIFT DOES NOT TURN ON - DC

All voltages are referenced to Battery ground. Using a voltmeter, place the negative probe directly to the negative pole of the battery. If equipped with battery back up, remove back up battery before proceeding. Disconnect both chassis connector and coil cord connector from the control box.

1) Turn off key switch and E-Stop switch. Check power connections on circuit board S28 and GND found on the lower right hand side of the circuit board. See drawing (Page 3-5).

1a) S28 is less than battery voltage.	a) Improperly connected or damaged motor harness. b) Poor battery connections.
1b) GND is not zero volts.	a) Improperly connected or damaged motor harness.
1c) Battery voltage is found at S28 and zero volts is found on GND.	a) Battery power is present at PCB. Continue to step 2.

2) Check for voltage at the terminals of the key switch. Turn the key switch on and the E-Stop switch off.

2a) No voltage is found on either terminal.	a) Circuit board is damaged. Replace circuit board.
2b) Voltage is found only on one of the two key switch terminals.	a) Ignition key switch is faulty. Replace ignition key switch.
2c) Voltage is found at both sides of the key switch.	a) Key switch is working properly. Continue to step 3.

3) Check for voltage at the terminals of the key switch. Turn the key switch on and the E-Stop switch off.

3a) Voltage at pin 6 does not exist or is less than 11 volts DC.	a) Circuit board is damaged.
3b) Voltage at ground pin 1 is not zero.	a) Circuit board is damaged. b) Ground on motor harness damaged or connected improperly.
3c) Voltage at pin 6 is between 10 and 12 VDC, voltage at pin 1 is zero.	Continue to step 4.

4) Plug in Chassis harness. Turn on ignition key, turn off E-Stop switch. Check voltages at pin 1 and pin 6 of the chassis harness. This may require the use of a sharp probe to pierce the insulation of the corresponding wires.

4a) Pin 6 is not between 10 and 12 VDC.	a) Damaged or shorted chassis harness.
4b) Voltage at ground pin 1 is not zero.	a) Circuit board is damaged. b) Ground on motor harness damaged or connected improperly.

LIFT DOES NOT RAISE - DC

1) Does the lift turn on? Make sure all outriggers are extended and raised. Turn off the E-Stop switch and turn on the ignition key. Wait five seconds for machine to turn on and outrigger lifts to light.

1a) Outrigger lights do not turn on.	a) See section LIFT DOES NOT TURN ON.
1b) Outrigger lights turn on immediately and five second delay is not present.	b) Circuit board is damaged. Replace circuit board.
1c) Fewer than four indicator lights operate.	a) Indicator light is damaged. b) Chassis harness damaged or incorrectly connected. c) Outrigger limit switch defective or improperly connected.
1d) All four indicator lights turn on five seconds after ignition key is turned on.	a) Continue to step 2.

2) Pull out both E-Stop switches. Activate the common and up switch on the upper control box.

2a) Motor does not run.	a) Continue to step 3.
2b) Motor runs but will not raise.	a) Hydraulic system failure. b) Coil cord is damaged c) Damaged or improperly connected pump solenoids.
2c) Lift turns off and restarts in five seconds.	a) Improperly connected or damaged motor harness. b) Improperly connected or damaged coil cord or upper control box. c) Damaged pump solenoid or motor solenoid. d) Battery charge is low.

3) Open the lid on the lower control box. Check for voltage at the E-Stop switch. Ignition key is turned on E-Stop is pulled out on both the upper box and lower box.

3a) No voltage is present at either of the terminals on the E-Stop switch.	a) Circuit board is damaged. Replace circuit board.
3b) Voltage is present on both terminals of the E-Stop switch.	a) Check for correct operation of upper E-Stop switch. Continue to step 4.
3c) Voltage is only present at one side of the E-Stop switch.	a) Replace E-Stop switch in whole or in part.

4) Click circuit board lift circuit. Place voltmeter probe at terminal S26 at the upper right hand side of the circuit board. See drawing (Page 3-5). Activate the common and up switch on the upper control box.

4a) When button is pressed, 10-12 VDC is not present at pin S26.	a) Improperly connected or damaged coil cord or upper control box. b) Damaged circuit board.
4b) When up button is pressed, 10-12 VDC is present at pin S26.	a) Damaged or improperly wired motor harness. b) Damaged motor starter relay.

Table 3-1: Troubleshooting (cont'd)

LIFT DOES NOT LOWER - DC

1) Lift will raise but will not lower. Turn on key switch, pull out both upper and lower E-Stops. Press the common and down push buttons on the upper control box.

1a) Lift turns off and restarts in five seconds.	a) Improperly connected or damaged motor harness. b) Improperly connected or damaged coil cord or upper control box. c) Damaged down solenoid.
1b) Lift will not lower.	a) Continue to step 2.

2) Check circuit board for correct output. Open lid on the lower box. Using a voltmeter, check the voltage on terminal S27 found on the upper right hand side of the circuit board. See drawing. Turn on ignition key and pull out both E-Stop switches. Depress the common and down switches on the upper control box.

2a) Lift turns off and restarts in five seconds.	a) Improperly connected or damaged motor harness. b) Improperly connected or damaged coil cord or upper control box. c) Damaged down solenoid.
2b) Lift will not lower.	a) Continue to step 2.




Figure 3-1: Circuit Board

NOTES:

4.0 Introduction

This section contains electrical and hydraulic power schematics and associated information for maintenance purposes.

The diagrams are to be used in conjunction with *Table 3-1: Troubleshooting Guide*. They allow understanding of the makeup and functions of the systems for checking, tracing, and faultfinding during troubleshooting analysis.

The components that comprise the electrical and hydraulic systems are given a reference designation and are explained as to function and location in the following tables.

LIST OF FIGURES

Figure	Page
Figure 4-1: Electrical Schematic, AC Models	4-3
Figure 4-2: Electrical Schematic, DC Models	4-3
Figure 4-3: Hydraulic Schematic	4-4

4.1 Electrical Schematics

Table 4-1: Electrical Schematic Legend AC

REFERENCE DESIGNATION	NAME	FUNCTION	LOCATION
BR	Bridge Rectifier	Converts AC to DC for control circuit.	In Control Box.
C1-4	Relay Contacts Norm. Open for R1-4.	Completes ground circuit to motor and Lift Valve when R1-4 are energized.	In Control Box.
L1-4	Indicator Light	Lights when Outrigger Interlock Switches are closed.	On chassis next to Outrigger socket.
M1	Electric Motor	Supplies power to drive hydraulic pump.	Upper portion of Power Unit.
R1-4	Relay Coil	When energized closes relay contacts 1-4.	In Control Box.
R5	Motor Contactor	Switches power to Electric Motor.	In Control Box.
S1	Switch, Chassis Emergency Stop	Control circuit shut off.	In Control Box.
S2	Switch, Key	Provides power to upper controls.	In Control Box.
S3	Switch, Platform Emergency Stop	Control Circuit shut off.	In Control Box.
S4	Switch. Power On	Supplies power to either Up or Down Switch.	Center button of platform controls.
S5	Switch, Lift	Supplies power to up circuit.	Upper button of platform controls.
S6	Switch, Lower	Supplies power to down circuit.	Lower button of platform controls.
S7-10	Switch, Outrigger Interlock	Supplies power to L1-L4 and R1-R4.	In Outrigger Sockets.
SOL1	Solenoid, Lower (coil)	Opens down valve.	Power Unit front.
SOL2	Solenoid, Lift (coil)	Opens Up Valve.	Power Unit left hand side.
T1	Transformer	Steps down AC voltage.	Inside electrical Control Box.

Table 4-2: Electrical Schematic Legend DC

REFERENCE DESIGNATION	NAME	FUNCTION	LOCATION
BAT	Battery	Supplies current to circuit.	In Power Module.
CH	Charger	Maintains Charge level in Battery.	In Power Module.
C1-4	Relay Contacts Norm. Open for R1-4.	Completes ground circuit to motor and Lift Valve when R1-4 are energized.	In Control Box.
L1-4	Indicator Light	Lights when Outrigger Interlock Switches are closed.	On chassis next to Outrigger socket.
M1	Electric Motor	Supplies power to drive hydraulic pump.	Upper portion of Power Unit.
R1-4	Relay Coil	When energized closes relay contacts 1-4.	In Control Box.
R5	Relay, Motor	Supplies power to Motor.	Lower Power Module.
S1	Switch, Chassis Emergency Stop	Control circuit shut off.	In Control Box.
S2	Switch, Key	Provides power to upper controls.	In Control Box.
S3	Switch, Platform Emergency Stop	Control Circuit shut off.	In Control Box.
S4	Switch. Power On	Supplies power to either Up or Down Switch.	Center button of platform controls.
S5	Switch, Lift	Supplies power to up circuit.	Upper button of platform controls.
S6	Switch, Lower	Supplies power to down circuit.	Lower button of platform controls.
S7-10	Switch, Outrigger Interlock	Supplies power to L1-L4 and R1-R4.	In Outrigger Sockets.
SOL1	Solenoid, Lower (coil)	Opens down valve.	Power Unit front.
SOL2	Solenoid, Lift (coil)	Opens Up Valve.	Power Unit left hand side.




Figure 4-1: Electrical Schematic, AC Models




Figure 4-2: Electrical Schematic, DC Models

4.2 Hydraulic Schematic

Table 4-3: Hydraulic Schematic Legend

REFERENCE DESIGNATION	NAME	FUNCTION	LOCATION
CV	Valve, Check	Allows flow in one direction.	Valve Block Assembly
CYL	Cylinder	Operates Lift	On lift assembly.
FLT	Filter	Seperates matter held in suspension from fluid.	Inline with Pump.
ORF	Orifice	Controls flow out of CYL.	Inline with CYL.
P	Pump	Supplies hydraulic pressure to system.	Lower Power Module.
RV	Relief Valve	Limits maximum pressure by releasing oil.	Valve Assembly Lower Power Module.
V1	Valve, Two-Way Norm. Open	Stops flow when energized.	Valve Block Assembly.
V2	Valve, Two-Way Norm. Closed	Allows flow when energized.	Lift Cylinder Assembly.




Figure 4-3: Hydraulic Schematic

UpRight

Call Toll Free in U.S.A.

1-800-926-LIFT

UpRight, Inc.

1775 Park Street
Selma, California 93662

TEL: 559/891-5200

FAX: 559/891-9012

PARTS: 1-888-UR-PARTS

PARTS FAX: 559/896-9244

UpRight

Call Toll Free in U.S.A.

1-800-926-LIFT

**UpRight International
Support Centre**

Innsbruckweg 114
3047 AH Rotterdam
Netherlands

TEL: +31-10-238-0000

FAX: +31-10-238-0001

Parts Tel: +31-10-490-8090

Parts Fax: +31-10-490-8099