

SERVICE INFORMATION SI03.01

Machines/Models: MX19 Serial Numbers:17500 - CUrrent

DATE: AUGUST 01, 2003

PURPOSE: Replacing 069199-000 battery charger with 069199-001 battery charger

READ ALL INSTRUCTIONS AND REVIEW ALL FIGURES BEFORE PERFORM-ING THE FOLLOWING INSTRUCTIONS

1. Disconnect battery cable quick disconnect.

2. Remove existing charger and retain mounting hardware.

- 3. Remove and discard adapter plate from new charger as shown in **FIGURE 1**
- 4. Set new charger into channel and move as close to out side of door as possible. Use the charger as a template, mark and drill two 3/8" holes for new mounting location. FIGURE 2
- 5. Reinstall mounting hardware.
- 6. Route charger wiring, cut to length and reinstall in the same fashion as it was removed. Reconnect battery cable quick disconnect.





FIGURE 1 FIGURE 2

If you have any questions regarding this Service Bulletin, please contact the UpRight Product Support Department by telephone at (800) 926-5438 from within the USA or at (559) 662-3900 From Europe countries + 353 (0) 1 620 9300 (Ireland)

Page 1 of 1